G180- Expansion joint

Application instructions

G180 is used to allow for expansion on large roofs (over 50m²) it also acts as an integral gutter to aid drainage. The decking should be cut to allow for an adequate gap in which to insert the trim. the flanges of the trim should be parallel with the decking. The trim should then be nailed to the decking. The join between where the trim edges are nailed and the decking should then be bandaged and the laminate should be applied over the trim.



